# Alphabetical index

,		
7	۱	
r	٦	

### A A/C

Air conditioning filter549	)
Automatic air conditioning	
system262, 270, 280	)
Front air conditioning	
system262, 270	)
Rear air conditioning system280	)
ABS223	
ACCESSORY mode164	•
AFS189	
Adaptive front lighting system189	
Air conditioning filter549	)
Air conditioning system	
Air conditioning filter549	)
Front air conditioning	
system262, 270	
Rear air conditioning system280	)
Airbags	
Airbag operating conditions124	r
Airbag precautions for your	
child129	)
Airbag warning light600	)
Curtain shield airbag operating	
conditions125	)
Curtain shield airbag	
precautions129	)
Front passenger occupant	
classification system134	
General airbag precautions129	
Locations of airbags120	)
Modification and disposal of	
airbags133	
Proper driving posture118, 129	1
Side airbag operating	
conditions125	
Side airbag precautions129	
SRS airbags120	)

Alarm	115
Antenna	298
Anti-lock brake system	223
Armrest	464
Ashtrays	452
Audio input	341
Audio system	
Antenna	.298
Audio input	341
Audio visual input	.383
AUX adapter	341
A/V input adapter	.383
CD player/changer	
DVD player299, 358,	
MP3/WMA disc306,	362
Optimal use	337
Portable music player	341
Radio	294
Rear seat audio system	342
Rear seat entertainment	
system	.348
Steering wheel audio switch	.346
Audio visual input	.383
Automatic air conditioning system	ı
Air conditioning filter	549
Automatic air conditioning	
system262, 270,	280
Front air conditioning	
system262,	270
Rear air conditioning system	.280
Automatic headlight leveling	
system	. 190
Automatic light control system	
AUX adapter	
A // input adaptor	383

3	Back-up lights	Child restraint system
	Wattage649	Booster seats, definition139
	Battery	Booster seats, installation144
	Checking531	Convertible seats, definition139
	Hybrid battery	Convertible seats, installation144
	(traction battery)33	Front passenger occupant
	If the vehicle has discharged	classification system134
	12-volt battery628	Infant seats, definition139
	Preparing and checking before	Infant seats, installation144
	winter246	Installing CRS with lower
	Bluetooth <sup>®</sup> 387	anchors148
	Brakes	Installing CRS with seat belts144
	Fluid529	Installing CRS with top straps 149
	Brake hold176	Child safety
	Parking brake174	Airbag precautions129
	Brake assist223	Child restraint system139
	Brake hold176	Child-protectors64
		How your child should wear the
( )	Care	seat belt94
	Exterior500	Installing child restraints144
	Interior503	Moon roof precautions105
	Seat belts504	Power window lock switch103
	Cargo capacity241	Power window precautions 104
	Cargo hooks477	Removed electronic key battery
	CD changer302	precautions553
	CD player302	Seat belt comfort guide92
	Chains246	Seat belt extender precautions96
		Seat belt precautions95
		Seat heater precautions463
		Trunk precautions70
		12-volt battery
		precautions533, 630

Child-protectors	64
Cigarette lighter	453
Cleaning	
Exterior	500
Interior	503
Seat belts	504
Climate control seat	460
Climate control seat filter	462
Clock	449
Coat hooks	475
Coin holder	437
Condenser	528
Console box	439
Cool box	441
Cooling system	
Hybrid system overheating	631
Corner assist sensors	209
Cruise control	
Cruise control	196
Dynamic radar cruise	
control	199
Cup holders	438
Curtain shield airbags	120
Customizable features	664

Daytime running light system	189
Defogger	
Rear window	288
Side mirrors	288
Dimensions	638
Dinghy towing	251
Display	
Energy flow	34
Multi-information display	
Touch screen	
Trip information	185
Warning message	608
Do-it-yourself maintenance	
Door courtesy lights	
Door courtesy lights	430
Wattage	
Door pockets	
Doors	
Door glasses	103
Door lock 46, 6	
Side mirrors	
Driver's seat belt reminder light	
Driving	
Correct posture	118
Procedures	
Driving position memory	
DVD 1 200 250	

Electric power steering223
Electronically modulated air
suspension218
Electronic key
If the electronic key does not
operate properly625
Emergency, in case of
If the electronic key does not
operate properly625
If the hybrid system will not
start619
If the parking brake cannot be
released622
If the shift lever cannot be shifted
from "P"621
If the vehicle has discharged
12-volt battery628
If the warning buzzer
sounds599
If the warning light turns on599
If the warning message is
displayed608
If you have a flat tire611
If you lose your keys624
If you think something is
wrong596
If your vehicle becomes
stuck635
If your vehicle needs to be
towed590
If your vehicle overheats631

Engine	
Accessory mode	163
Compartment	518
Engine switch	163
Hood	515
How to start the hybrid	
system	163
Identification number	.639
If the hybrid system will not	
start	619
Ignition switch	163
Overheating	631
"POWER" switch	163
Engine compartment cover	519
Engine/power control unit coolar	nt
Capacity	643
Checking	526
Preparing and checking before	
winter	246
Engine oil	
Capacity	642
Checking	521
Preparing and checking before	
winter	246
Engine oil maintenance data	.524
Engine switch	163
EPS	.223
EV drive mode switch	167
Event data recorder	.597

F	First-aid kit storage belt477	G	Gara
	Floor mat476		Gaug
	Fluid		Glove
	Brake529		
	Washer530	Н	Hand
	Fog lights		(for
	Switch191		Head
	Wattage649		Ac
	Footwell lighting430		Head
	Front fog lights		Head
	Switch191		Head
	Wattage649		Dis
	Front passenger occupant		p
	classification system134		Re
	Front passenger's seat belt		Sw
	reminder light601		W
	Front seats		Heate
	Adjustment73		Se
	Driver's seat position memory83		Sic
	Front turn signal lights		Ste
	Wattage649		Heigh
	Fuel		Ele
	Capacity640		S
	Fuel gauge178		Hill-st
	Information650		Hood
	Refueling108		Hook
	Fuel door108		Ca
	Fuel filler door108		Сс
	Fuses554		Sh

Garage door opener	480
Gauges	178
Glove box	436
Hands-free system	
(for cellular phone)	387
Head restraints	
Adjustment	89
Headlight aim	575
Headlight cleaner	195
Headlights	
Discharge headlight	
precautions	587
Replacing light bulbs	577
Switch	188
Wattage	649
Heaters	
Seat heaters	460
Side mirrors	288
Steering wheel	458
Height control	
Electronically modulated air	
suspension	218
Hill-start assist control	
Hood	515
Hooks	
Cargo	477
-	
	Gauges

	Hybrid system	K	Keyless entry	60
	Emergency shut off system34		Keys	
	Energy monitor/consumption		Electronic key	42
	screen34		If the electronic key does not	
	Engine switch163		operate properly	625
	High voltage components33		If you lose your keys	624
	Hybrid system indicator178		Key number	42
	Ignition switch163		Keyless entry	60
	"POWER" switch164		Keys	42
			Mechanical key	43
I	I/M test511		"POWER" switch	163
	Identification		Wireless remote control key	60
	Electric motor639			
	Engine639	L	Lexus link system	486
	Vehicle639		Light bulbs	
	Ignition switch163		Replacing	577
	Illuminated entry system430		Wattage	649
	Immobilizer system113		Lights	
	Indicator lights181		Door courtesy lights	430
	Initialization		Fog light switch	191
	Items to initialize669		Headlight switch	188
	Inside rear view mirror100		Interior light switch	432
	Interior lights		Outer foot lights	430
	Interior lights430		Overhead courtesy light	430
	Switch432		Personal light switch	432
	Wattage649		Replacing light bulbs	577
			Shift lever lighting	430
J	Jack		Turn signal lever	173
	Positioning a floor jack516		Vanity lights	448
	Replacing the wheel611		Wattage	649
	Jack handle 611		Load capacity	244

М	Maintenance	Outside rear view mirrors
	Do-it-yourself maintenance512	Adjusting and folding101
	General maintenance508	Mirror position memory83
	Maintenance data638	Outside temperature display185
	Maintenance requirements 506	Overhead console445
	Meter	Overhead courtesy lights
	Instrument panel light control179	Overhead courtesy lights430
	Meters178	Wattage649
	Micro dust and pollen	Overheating, Hybrid system631
	filter266, 276	
	Mirrors P	Parking assist sensors209
	Inside rear view mirror100	Parking brake174
	Side mirror heaters288	Parking lights
	Side mirrors101	Replacing light bulbs577
	Vanity mirrors448	Switch188
	Moon roof105	Wattage649
	MP3 disc306, 362	PCS229, 232
	Multi-information display184	Penlight612
		Personal lights
0	Odometer178	Switch432
	Oil	Power outlet455
	Engine oil521	"POWER" switch164
	Opener	Power windows103
	Fuel filler door108	Pre-collision system229, 232
	Hood515	
	Trunk68	
	Outer foot lights	
	Outer foot lights430	
	Wattage649	

D 1	100
Radar cruise control	199
Radiator	.528
Radio	294
Radio data system	296
Rear seat	
Seat adjustment7	6,79
Seat position memory	87
Rear seat entertainment	
system	.348
Rear seat relaxation system	. 465
Rear sunshade	469
Rear turn signal lights	
Replacing light bulbs	577
Wattage	649
Rear view monitor system	. 220
Rear window defogger	.288
Replacing	
Electronic key battery	552
Fuses	554
Light bulbs	577
Reporting safety defects for U.S.	
owners	672
	Seat adjustment

### S Seat belts

Adjusting the seat belt	92
Automatic locking retractor	93
Child restraint system	
installation	139
Cleaning and maintaining the se	eat
belts	.504
Emergency locking retractor	93
How to wear your seat belt	91
How your child should wear the	3
seat belt	94
Pregnant women, proper seat k	oelt
use	93
Reminder light	601
Seat belt extenders	94
Seat belt pretensioners	92
Seat heaters	.460
Seat position memory8	3, 87
Seating capacity	.244

Seats
Adjustment73, 76, 79
Adjustment
precautions75, 78, 82
Child seat/child restraint system
installation139
Cleaning503
Climate control460
Climate control seat460
Driver's seat position memory83
Head restraint89
Properly sitting in the seat118
Rear seat position memory87
Rear seat relaxation system465
Seat heaters460
Seat position memory
Service reminder indicators181
Shift lever
If the shift lever cannot be
shifted from "P"621
Transmission
Shift lever lighting430
Shift lock system
Shopping bag hooks477
Side airbags120
Side marker lights
Switch188

Side mirrors	
Adjusting and folding	101
Mirror position memory	83
Smart access system with push	-button
start	
Entry function	46
Starting the hybrid system	163
Spare tire	
Inflation pressure	543
Spare tire	611
Spark plug	643
Specifications	638
Speedometer	178
Steering wheel	
Adjustment	98
Audio switches	346
Heated steering wheel	458
Steering wheel position	
memory	83
Storage feature	434
Stuck vehicle	
If your vehicle becomes	
stuck	635
Sun visors	447
Sunshades	
Rear	469
Rear door	472
Df	106

### Switch

170
163
167
19
458
163
188
174
63
163
68
68
103
103
192

н	г	
ı		
L		

Tachometer	178
Tail lights	
Switch	188
Theft deterrent system	
Alarm	115
Immobilizer system	113
Theft prevention labels	
Tire inflation pressure	
Tire information	
Glossary	658
Size	655
Tire identification number	
Uniform tire quality grading	656
Tires	
Chains	246
Checking	535
If you have a flat tire	
Inflation pressure	
Inflation pressure sensor	
Information	
Replacing	
Rotating tires	
Size	
Snow tires	246
Tire pressure warning	
system53	35, 60
Tools	61
Total load capacity	244
Touch screen	
Towing	
Dinghy towing	25
Emergency towing	
Trailer towing	

TDAG	222	M	
TRAC		Warning buzzers	
Traction control	223	Open door	
Transmission		Seat belt reminder	601
If the shift lever cannot be		Warning lights	
shifted from "P"		Anti-lock brake system	
"S" mode		Brake assist system	
Transmission		Brake system5	
Trip meter	178	Charging system	599
Trunk		Electric power steering	600
Closer	68	High coolant temperature	601
Opener	68	Low fuel level	601
Trunk light		Low tire pressure	601
Wattage	649	Malfunction indicator lamp.	600
Turn signal lights		Master warning light	601
Replacing light bulbs	577	Open door	601
Switch	173	Pre-collision system	600
Wattage	649	Pretensioners	600
		Seat belt reminder light	601
Vanity lights		SRS airbags	600
Vanity lights	448	Tire pressure	601
Wattage		Warning messages	608
Vanity mirrors		Washer	
VDIM		Checking	530
Vehicle dynamics integrated		Preparing and checking bef	fore
management	223	winter	
Vehicle identification number		Switch	192
Vehicle stability control		Washing and waxing	
VSC		Weight	
V 3C	223	Cargo capacity	241
		Load limits	
		Weight	
		Wheels	
		Window glasses	
		Window lock switch	
		TTINGOW IOCK SWITCH	

####